

---

## Table Of Contents

---

Section	Description	Page #
<b>7.</b>	<b>Pump Module LF Multiplex Lip/Face Seal.....</b>	<b>7-2</b>
7.1	Description .....	7-2
7.2	Operation .....	7-2
7.2.1	Piston/Valve/Cylinder Set .....	7-2
7.3	Installation .....	7-3
7.4	Options .....	7-3
7.4.1	Special Piston/Cylinder Bore Clearances or Modifications .....	7-3
7.4.2	Fitting Sets .....	7-3
7.5	Maintenance .....	7-3
7.5.1	Preventative Maintenance .....	7-3
7.5.1.1	General Applications; Routine Cleaning Procedure. ....	7-4
7.5.2	Assembly/Disassembly Procedures .....	7-4
7.5.2.1	Pump Module .....	7-4
7.5.2.2	Piston/Cylinder/Valve .....	7-7
7.5.2.3	Case .....	7-8
7.5.2.4	End Caps .....	7-9
7.5.2.5	Washer .....	7-9
7.5.2.6	Lip/Face Seals .....	7-9
7.6	Problem Guide .....	7-10
7.6.1	Piston Seized In The Cylinder .....	7-10
7.7	Specifications .....	7-10
7.8	Model Number .....	7-11
7.9	Illustrated Parts Breakdown .....	7-11

## 7. PUMP MODULE LF MULTIPLEX LIP/FACE SEAL

### 7.1 DESCRIPTION (Figure 7.1)

The Lip/Face Seal LF Multiplex Pump Module, hereafter referred to as the Pump Module, is comprised of the following major components; a ceramic valve fabrication (hereafter referred to as the valve), a piston fabrication (hereafter referred to as the piston), a cylinder and a case. The Pump Module is within the liquid path and is designed to be detached from the Actuator Module and completely disassembled for ease of cleaning, decontamination and sterilization. The Pump Module is designed to be used in conjunction with the LF Multiplex Actuator Module.

### 7.2 OPERATION

The Pump Module is a piston/valve/cylinder arrangement providing positive displacement. The Pump Module contains a ceramic valve that is selectively rotated and a ceramic piston that is reciprocated by the Actuator Module. The valve and piston are connected to the Actuator Module through bearing balls located on each end of the Pump Module. The bearing balls compensate for angular misalignment. The valve incorporates a flat or slot on one end providing valving of the pump to either the intake or discharge ports.

The valve's normal dispensing position, after reference, is with the valve aligned with the discharge port. The piston's home position is retracted and ready for liquid dispensing. The piston is pushed forward forcing the specified amount of liquid through the discharge port. Depending on the Controller Module mode, the piston will either stop after completing a dispense and wait until requested to dispense again or the valve will rotate to the intake port, the piston will retract to fill the chamber and then the valve will rotate back to the discharge port.

The valve allows only one port to communicate with the pumping chamber at any time. This positive mechanical valving eliminates the need for check valves under normal operations.

#### 7.2.1 Piston/Valve/Cylinder Set

The piston/valve/cylinder set is constructed of high density alumina . The ceramics are compatible with most acids and bases. The valve/cylinder set has a clearance between the valve and cylinder wall of approximately .00005" (1.27 microns) which minimizes fluid slip.




Figure 7.1 LF Multiplex Pump Module

The ceramic piston and valve operate within the ceramic cylinder with no lubrication other than the liquid being dispensed or metered. The natural crystalline structure of the ceramic displays zero porosity ensuring zero retention and carryover of one liquid to the next.

The ceramic material's mechanical and thermal stability allows the valve to seal by virtue of a close running clearance between it and the cylinder bore. This means no compliant dynamic seals are used, eliminating a part requiring frequent replacement in traditional pump designs.

### 7.3 INSTALLATION

Installation of the Pump Module is required. Refer to section 7.5.2.1 for assembly and disassembly of the Pump Module to the Actuator Module. Refer to Chapter 2 for instructions on setting up the system for operation.

### 7.4 OPTIONS

IVEK Corporation offers a variety of options to best meet the customers' needs. Following is a list and description of available options for the Pump Module. Refer to the Title Section of this manual for the list of options provided with this system.

#### **7.4.1 Special Piston/Cylinder Bore Clearances or Modifications**

For certain applications, special modifications are required between the piston/valve and cylinder bore. IVEK Corporation determines these modifications by performing application tests using the application fluid. Contact IVEK Corporation Applications Department for more information.

#### **7.4.2 Fitting Sets**

Fitting sets are available with the Pump Module. Each fitting set is composed of a fitting, fitting seals and fitting retainers. The following types of fittings are available from IVEK Corporation.

- O-Ring Face Seal Fittings Compatible W/"Cajun" 2-VCO 7 4-VCO
- Barbed Tubing Adapters 1/8", 3/16", 1/4", 3/8", 1/2"
- Pipe Thread Adapters 1/8"&1/4" NPT
- 1/4 - 28 & 5/16 - 24 Adapters For "Upchurch Flangeless Tube Fittings"
- Sanitary Adapter Fittings
- Compression Fitting Adapter Compatible W/"JACO" 0 - 4, P6 - 4
- Compression Fitting Adapter Compatible W/"Swagelock 402 - 1, 404 - 1 & 403 - 1
- Compression Fittings Compatible W/"Swagelock 200 - 1, 204 - 1 & 203 - 1

### 7.5 MAINTENANCE

#### **CAUTION**

*Never forcibly remove or install the piston or valve into the cylinder housed within the Pump Module. Damage to the equipment may result.*

#### **7.5.1 Preventative Maintenance**

The ceramic components for the Pump Module have been designed to last for millions of repetitions without wear. Preventative maintenance includes careful handling of the piston, valve and cylinder housing when they have been removed from the Pump Module. Always take great care when removing the piston or valve from the cylinder and replacing the piston or valve into the cylinder. If the cleaning procedure includes removing the Pump Module and individually cleaning separate parts, always keep the Pump Module parts together. Each piston, valve and cylinder are serialized and must always be reassembled as a matched set. Never clean in such a way that the ceramics can vibrate against each other or chipping and scratching may result.

**CAUTION**

*Ceramic piston/valve/cylinder sets are particularly sensitive to neglect and may seize if allowed to dry out without adequate cleaning.*

**7.5.1.1 General Applications; Routine Cleaning Procedure.**

1. Once the Pump Module has been emptied, disconnect intake tubing from process liquid supply container.
2. Cycle pump in continuous mode until remaining process liquid has been purged from the Pump Module liquid path.
3. Connect the intake tubing to the cleaning liquid supply container.
4. Cycle pump in continuous mode at a high prime rate to flush the cleaning liquid through the entire liquid path.
5. Repeat step 4 using water and/or alcohol.

**NOTE**

*Routine flushing with a compatible liquid after shutdown will suffice for most applications.*

**7.5.2 Assembly/Disassembly Procedures (Figure 7.2)**

The Pump Module contains the following replaceable parts. Also contained in this section are the procedures for assembling and disassembling the Pump Module from the Actuator Module.

**CAUTION**

*Torque the castellated sleeves (5 and 6) on the Pump Module to 12 in lbs. (1.356 N m). The Pump Module may not operate properly if excessive pressure is placed on the valve. Refer to Figure 7.4.*

**NOTE**

*The lip seals (3 and 8) are identical and may be cleaned and interchanged during assembly.*

- Ceramic Piston Fabrication (1)
- End Caps (2 and 11)
- Lip/Face Seals (3 and 8)
- Case (4)
- Castellated Sleeves (5 and 6)
- Ceramic Cylinder (7)
- Valve Retainer Washer (9)
- Ceramic Valve Fabrication (10)

**WARNING**

*Make sure the power is OFF and all hazardous liquids have been flushed from the system prior to performing any disassembly or assembly procedures.*

**7.5.2.1 Pump Module (Figure 7.3)**

The following procedure is necessary if you received a new Pump Module or for removal and installation if removing the Pump Module for replacement, maintenance or repair.

Removal: (Figure 7.3)

**CAUTION**

*Position the upper coupler as shown in figure 7.2, A.*




Figure 7.2 Lip/Face Seal LF Multiplex Pump Module Components Assembly/Disassembly




Figure 7.3 LF Multiplex Pump Module Assembly/Disassembly

**View A**

1. Remove all tubing from front and rear Ports (3) on Pump Module (4).

**View B**

2. Push slide door (6) down.

**View C**

3. Place a finger behind piston (5) and pull forward to remove the lower section of Pump Module (4) from the Actuator Module making sure you hold piston (5) to prevent it from falling out of Pump Module (4).

**View D**

4. Rotate Pump Module (4) 90° and pull valve bearing ball (2) out of coupling assembly (1).

Installation:

**View D**

1. Position valve bearing ball (2) in coupling assembly (1) making sure the flat side faces up and the slots in valve bearing ball (2) align with locator pins in coupling assembly (1).
2. Slide valve bearing ball (2) into coupling (1) until it is fully seated.

**CAUTION**

*If pump module is rotated into position per step 3 without valve bearing ball being completely seated in the coupler and the flat facing outward as shown, damage to the coupler and/or valve ball may result.*

**View C**

3. Rotate Pump Module (4) 90° making sure the alignment pin and rear port (3) fit into the holes on the rear panel.
4. Push piston bearing ball (7) into the slide assembly socket.

**View B**

5. Push slide door (6) up to secure piston ball in place.

**7.5.2.2 Piston/Cylinder/Valve (Figure 7.2 Items 1, 7 and 10)****NOTE**

*The piston, valve and cylinder are factory matched and serialized and cannot be sold individually or interchanged with other Pump Modules.*

**Disassembly**

1. Remove the Pump Module from the Actuator Module as described in section 7.5.2.1.
2. Remove ceramic piston fabrication (1) from ceramic cylinder (7) by slowly pulling and turning ceramic piston fabrication (1) while holding case (4).
3. Remove end cap (2) from case (4) by turning in a counter clockwise direction.
4. Remove end cap (11) from case (4) by turning in a counter clockwise direction.
5. Remove ceramic valve fabrication (10) with washer (9) from ceramic cylinder (7) by slowly pulling and turning ceramic valve fabrication (10) while holding case (4).
6. Remove Sleeves (5 and 6) from case (4) by turning in a counter clockwise direction.
7. Gently push ceramic cylinder (7) with seals (3 and 8) out of case (4).

## Assembly

### NOTE

*End caps (2) and (11) and seals (3) and (8) are identical and may be interchanged during assembly.*

1. Slide ceramic cylinder (7) into case (4). Make sure the groove on ceramic cylinder (7) lines up with the pin on case (4).
2. Insert seals (3 and 8) with exposed spring towards ceramic cylinder (7) into case (4).
3. Secure sleeves (5 and 6) to case (4) by turning in a clockwise direction, finger tighten.
4. Slide washer (9) onto valve fabrication (10).
5. Install ceramic valve fabrication (10) and washer (9) into ceramic cylinder (7) by slowly pushing and turning ceramic valve fabrication (10) while holding case (4).
6. Secure end cap (11) to case (4) by turning in a clockwise direction keeping the port in the cylinder centered in the case.
7. Secure end cap (2) to case (4) by turning in a clockwise direction using #2 and #11. Be sure the port holes in the cylinder are centered in the case.
8. Install ceramic piston fabrication (1) into ceramic cylinder (7) by slowly pushing and turning ceramic piston fabrication (1) while holding case (4).
9. Install the Pump Module onto the Actuator Module as described in section 7.5.2.1.

### 7.5.2.3 Case (Figure 7.2 Item 4)

#### Disassembly

1. Remove the Pump Module from the Actuator Module as described in section 7.5.2.1.
2. Remove ceramic piston fabrication (1) from ceramic cylinder (7) by slowly pulling and turning ceramic piston fabrication (1) while holding case (4).
3. Remove end cap (2) from case (4) by turning in a counter clockwise direction.
4. Remove end cap (11) from case (4) by turning in a counter clockwise direction.
5. Remove ceramic valve fabrication (10) with washer (9) from ceramic cylinder (7) by slowly pulling and turning ceramic valve fabrication (10) while holding case (4).
6. Remove Sleeves (5 and 6) from case (4) by turning in a counter clockwise direction.
7. Gently push ceramic cylinder (7) with seals (3 and 8) out of case (4).

## Assembly

### NOTE

*End caps (2) and (11) and seals (3) and (8) are identical and may be interchanged during assembly.*

1. Insert seals (3 and 8) with exposed spring towards ceramic cylinder (7) into opening in ceramic cylinder (7). Make sure it sits flush with ceramic cylinder (7).

Customer supplied  
torque wrench with  
1/4" socket adapter

IVEK Spanner Wrench  
Part # 142017



**Figure 7.4 Torque Setup for Fittings (12)**



2. Slide ceramic cylinder (7) with seals (3 and 8) into case (4). Make sure the groove on ceramic cylinder (7) lines up with the pin on case (4).
3. Secure sleeves (5 and 6) to case (4) by turning in a clockwise direction, finger tighten.
4. Slide washer (9) onto valve fabrication (10).
5. Install ceramic valve fabrication (10) and washer (9) into ceramic cylinder (8) by slowly pushing and turning ceramic valve fabrication (10) while holding case (4).
6. Secure end cap (11) to case (4) by turning in a clockwise direction.
7. Secure end cap (2) to case (4) by turning in a clockwise direction.
8. Install ceramic piston fabrication (1) into ceramic cylinder (7) by slowly pushing and turning ceramic piston fabrication (1) while holding case (4).
9. Torque sleeves (5 and 6) to 12 in lbs. (1.356 N m) as shown in Figure 7.4.
10. Install the Pump Module onto the Actuator Module as described in section 7.5.2.1.

#### 7.5.2.4 End Caps (Figure 7.2 Items 2, 11)

##### Disassembly

1. Remove the Pump Module from the Actuator Module as described in section 7.5.2.1.
2. Remove ceramic piston fabrication (1) from ceramic cylinder (7) by slowly pulling and turning ceramic piston fabrication (1) while holding case (4).
3. Remove end cap (2) from case (4) by turning in a counter clockwise direction.
4. Remove end cap (11) from case (4) by turning in a counter clockwise direction.

##### Assembly

#### NOTE

*The lip seals (3 and 8) are identical and may be cleaned and interchanged during assembly.*

1. Secure end cap (11) to case (4) by turning in a clockwise direction.
2. Secure end cap (2) to case (4) by turning in a clockwise direction.
3. Install ceramic piston fabrication (1) into ceramic cylinder (7) by slowly pushing and turning ceramic piston fabrication (1) while holding case (4).
4. Install the Pump Module onto the Actuator Module as described in section 7.5.2.1.

#### 7.5.2.5 Washer (Figure 7.2 Items 9)

##### Disassembly

1. Remove the Pump Module from the Actuator Module as described in section 7.5.2.1.
2. Remove end cap (11) from case (4) by turning in a counter clockwise direction.
3. Remove washer (9).

##### Assembly

1. Slide washer (9) onto valve fabrication (10).
2. Secure end cap (11) to case (4) by turning in a clockwise direction.
3. Install the Pump Module onto the Actuator Module as described in section 7.5.2.1.

#### 7.5.2.6 Lip/Face Seals (Figure 7.2 Items 3 and 8)

##### Disassembly

1. Remove the Pump Module from the Actuator Module as described in section 7.5.2.1.

2. Remove ceramic piston fabrication (1) from ceramic cylinder (7) by slowly pulling and turning ceramic piston fabrication (1) while holding case (4).
3. Remove end cap (2) from case (4) by turning in a counter clockwise direction.
4. Remove end cap (11) from case (4) by turning in a counter clockwise direction.
5. Remove ceramic valve fabrication (10) with washer (9) from ceramic cylinder (7) by slowly pulling and turning ceramic valve fabrication (10) while holding case (4).
6. Carefully remove seals (3 and 8) from ceramic cylinder (7) without damaging cylinder (7).

## Assembly

### NOTE

*End caps (2) and (11) and seals (3) and (8) are identical and may be interchanged during assembly.*

1. Insert seals (3 and 8) with exposed spring towards ceramic cylinder (7) into opening in ceramic cylinder (7). Make sure it sits flush with ceramic cylinder (7).
2. Slide washer (9) onto valve fabrication (10).
3. Install ceramic valve fabrication (10) and washer (9) into ceramic cylinder (8) by slowly pushing and turning ceramic valve fabrication (10) while holding case (4).
4. Secure end cap (11) to case (4) by turning in a clockwise direction.
5. Secure end cap (2) to case (4) by turning in a clockwise direction.
6. Install ceramic piston fabrication (1) into ceramic cylinder (7) by slowly pushing and turning ceramic piston fabrication (1) while holding case (4).
7. Install the Pump Module onto the Actuator Module as described in section 7.5.2.1.

## 7.6 PROBLEM GUIDE

### 7.6.1 Piston Seized In The Cylinder

If the piston seizes in the cylinder perform the following steps.

### CAUTION

***DO NOT TRY TO FORCE THE PISTON FREE!***

*Damage to the piston/cylinder set or Actuator Module may occur.*

1. Remove the Pump Module from the Actuator Module as described in section 7.5.2.1.
2. Soak the Pump Module in a liquid compatible with the materials and process liquids.
3. After soaking, try removing the piston from the cylinder by applying a light torque to the piston using only your fingers (no tools).

If the aforementioned procedures fail, contact IVEK Technical Support Department for assistance for an RMA number if the unit needs to be returned. It may be necessary to ship the Pump Module back to the factory. Provide a note describing, in detail, what conditions caused the seizure. It may also be necessary to return the Actuator Module along with the Pump Module should realignment of the Pump Module drive components be required.

Table 7.2 contains a list of possible problems, causes and solutions for the Pump Module.

## 7.7 SPECIFICATIONS

Table 7.3 lists the volumetric output of the different size Pump Modules. Refer to the Title Page section of this manual for the Pump Module size provided with your system.

Table 7.3 Volumetric Output Of Multiplex Pump Modules

Pump Size	Chamber Capacity (µl)	Resolution (µl)
5000	5000	0.125
4000	4000	0.100
2000	2000	0.050

**7.8 MODEL NUMBER**

The model number provides important information about the specifics of your Pump Module. Refer to this number when calling IVEK Technical support. The model number for your Pump Module is located in the Title Page section of this manual.

202503 -		###	#
<b>Pump Size</b>			
200	2000µL		
400	4000µL		
500	5000µL		
<b>Lip Face Seal Size / Material</b>			
200	LF 2000, UHMWPE		
400	LF 4000, UHMWPE		
500	LF 5000, UHMWPE		
<b>Sleeve</b>			
1	Castellated and Threaded		
2	Knurled		

**7.9 ILLUSTRATED PARTS BREAKDOWN**

The illustrated parts breakdown (Figures 7.5) contains replacement parts for the Multiplex Pump Module.

Table 7.2 Common Operational Problems And Solutions

PROBLEM	PROBABLE CAUSE	POSSIBLE SOLUTION
Air evident in discharge line.	<p>Loose tubing connection at intake fitting.</p> <p>Loose/Damaged intake port seals.</p> <p>Loose/Damaged End Cap Seals or damaged intake fitting.</p> <p>Cavitation.</p>	<p>Tighten/replace fittings.</p> <p>Tighten/replace port seals.</p> <p>Clean, inspect and replace if necessary.</p> <p>Increase inlet tubing size, reduce Pump Module speed or increase feed pressure.</p>
Piston or valve seizing	Suspended or particulate materials in liquid entrapped between piston and cylinder.	Disassemble Pump Module and clean all wetted surfaces.
Fluid leaks	<p>Improperly seated or worn spring energized seal.</p> <p>Loose/damaged output port seal, output tubing, or damaged fitting.</p>	<p>Disassemble Pump Module and clean all wetted surfaces, inspect components and replace if necessary.</p> <p>Inspect, tighten or replace if necessary.</p>
Fluid not moving in tubing when priming, dispensing or metering.	<p>Pump Module not properly oriented on Actuator Module.</p> <p>The discharge tubing may be restricted.</p>	<p>Make sure the flat portion of the valve is positioned correctly.</p> <p>Make certain the port holes in the ceramic cylinder line up properly with the fittings.</p> <p>Check the tubing to make sure it is free from objects and no kinks are present.</p>




Figure 7.5 Pump Module LF Multiplex Lip/Face Seal (Sheet 1 of 2)

	PART NUMBER	DESCRIPTION	UNITS PER ASSY	
	202503-####	Pump Module LF Multiplex Lip/Face Seal	1	
<b>Model</b>	<b>Dwg</b>			
<b>#</b>	<b>Index</b>	<b>Part</b>		
<b>Tab</b>	<b>#</b>	<b>#</b>	<b>Description</b>	
			<b>Qty</b>	
2	2	202124	Cap, Case End, LF Multiplex Pump	2
4	4	202123	Machining/Fab, Case, LF Multiplex Pump	1
6	6	202211	Washer, Valve Retainer, Peek, LF Multiplex Pump	1
<b>202503 - (###) # CERAMIC SIZE Contains 1 of the Following:</b>				
200	1	022186-2000N	Piston/Valve/Cyl Set, LF Multiplex Pump, 2000ul, Alumina	1
400	1	022186-4000N	Piston/Valve/Cyl Set, LF Multiplex Pump, 4000ul, Alumina	1
500	1	022186-5000N	Piston/Valve/Cyl Set, LF Multiplex Pump, 5000ul, Alumina	1
<b>202503 - (###) # LIP SEAL MATERIAL / SIZE Contains 1 of the Following:</b>				
200	3	142805-2000	Seal, Lip/Rib, Spring Energized, UHMWPI; LF 2000	2
400	3	142805-4000	Seal, Lip/Rib, Spring Energized, UHMWPI; LF 4000	2
500	3	142805-5000	Seal, Lip/Rib, Spring Energized, UHMWPI; LF 5000	2
<b>202503 - ### (S) SLEEVE OPTIONS Contains 1 of the Following:</b>				
1	5	142084	Sleeve, Fitting Compression, Castellated & Threaded	2
2	5	142648	Threaded Sleeve, Knurled	2

Figure 7.5 Pump Module LF Multiplex Lip/Face Seal (Sheet 2 of 2)