
Table Of Contents

Section	Description	Page #
5.	Panel Mount Linear Actuator Module	5-2
5.1	Description	5-2
5.2	Operation	5-2
5.2.1	Sensors	5-3
5.2.1.1	Linear Sensor	5-3
5.2.1.2	Rotary Sensor	5-3
5.2.2	Coupling (hub)	5-3
5.2.3	Porting	5-3
5.2.3.1	Operation	5-4
5.2.3.2	Porting Adjustment	5-4
5.3	Installation	5-5
5.4	Options	5-5
5.4.1	Encoder	5-6
5.5	Maintenance	5-6
5.6	Problem Guide	5-7
5.7	Specifications	5-7
5.8	Model Number	5-8
5.9	Illustrated Parts Breakdown	5-8

5. PANEL MOUNT LINEAR ACTUATOR MODULE

5.1 DESCRIPTION (Figure 5.1)

The Panel Mount Linear Actuator Module, hereafter referred to as the Actuator Module, contains the mechanism for controlling the rotary and linear motion of the piston. The Actuator Module is composed of the motor, lead screw (either 20-pitch or 40-pitch), pump coupling, clutch/brake assembly, sensors and the cable connector.

Either a 20-pitch or 40-pitch model has been supplied depending on the size of the Pump Module chosen for your application. The 20-pitch Actuator Module is used for the B, C and D size pumps and measures 334mm (13.1") high, 95mm (3.7") deep, 140mm (5.5") wide and weighs approximately 4.3 kg (9.5 pounds). The 40-pitch Actuator Module is used for the "A" series pumps and measures 318.5mm (12.5") high, 95mm (3.7") deep, 140mm (5.5") wide and weighs approximately 4.1 kg (9.0 pounds). Both modules provide accurate control of the piston for precise dispensing volumes.

WARNING

Never remove a safety cover while the Actuator Module is running. Moving parts are located under these covers. Physical harm to individuals is possible.

5.2 OPERATION

The Actuator Module utilizes a permanent magnet stepping motor, a lead screw and an electromagnetic clutch and brake to produce a controllable linear and rotary motion. A linear displacement of the lead screw is produced by rotating a drive nut, internal to the stepping motor, while preventing the screw from rotating with the electromagnetic brake. Angular displacement steps of 1.8° produced by the stepping motor are thus converted to linear displacement steps at the screw. Angular displacement of the lead screw is accomplished by releasing the brake and coupling the lead screw to the motor drive nut through the electromagnetic clutch. The coupling of these members allows the stepping motor to impart a rotary motion to the lead screw.

Electronic control over these linear and rotary functions allows a mounted Pump Module to be driven so the linear motion is used to fill or empty the Pump Module and rotary motion is used to valve to the intake and discharge ports.




Figure 5.1 Panel Mount Actuator Module

5.2.1 Sensors

There are two sensors in the Actuator Module; both are used to control the stopping location of the lead screw. The linear sensor can either be magnetic or optical and is activated when the lead screw is in the linear home location. The rotary sensor is magnetic and is activated when the lead screw is in the rotary home location.

The sensor type is identified in the model number of the Actuator Module. The model number is located on the Actuator Module and in the Title Page section of the Operators Manual. A description of the Model Number is located in section 5.8 of this chapter.

5.2.1.1 Linear Sensor

The linear sensor sends a signal to the Controller Module when the lead screw is in the linear home position. When the cylinder is filling, the lead screw is drawing the piston back. When the cylinder is full, the lead screw activates the linear sensor stopping the piston. For a non-MCV actuator the linear home sensor detects a piston withdrawn to full chamber capacity. For an MCV actuator the linear sensor detects a piston that is in the empty chamber position. A fault can only be generated during a load operation (when using the standard operating methods).

5.2.1.2 Rotary Sensor

The rotary sensor sends a signal to the Controller Module when the lead screw is in the rotary home position. The rotary sensor is used to detect problems during rotation of the piston (valving between port A and B).

When power is first applied to the Controller Module, the piston needs to be referenced to the home position prior to operation (Refer to Chapter 3).

When a fault occurs, the piston needs to be referenced. At the completion of the reference cycle, the rotary position is determined by the Port setting on the Controller Module. If the setting is Port B, the piston flat will align to Port B. If the setting is Port A, the piston flat will align to Port A.

CAUTION

If the Controller Module is set for REVERSE and a fault occurs, the piston will reference to the selected port, but the Controller Module will revert back to FORWARD.

5.2.2 Coupling (hub)

A coupling, located on the pump side of the Actuator Module, provides a mounting location for the piston. The piston drive pin slides into a slot on the coupling hub and is secured with two set screws. A heavy-duty coupler is available for the 20-pitch actuator. This coupler provides greater longevity when dispensing viscous fluids at higher rates.

The coupling type is identified in the model number of the Actuator Module. The model number is located on the Actuator Module and in the Title Page section of the Operators Manual. A description of the Model Number is located in section 5.8 of this chapter.

CAUTION

The coupling is factory set to a precise location. Moving the coupling could cause damage to the Actuator Module or Pump Module.

WARNING

The linear actuator motor can generate a force capable of causing injury, especially during linear movement. The cover plate guards the operator from hand pinch hazards inside the coupler compartment. Do not remove the cover plate while the actuator is operating/powered. If the cover needs to be removed to view pump movement or coupler (e.g., for troubleshooting purposes), make sure it is performed by a trained

operator and take precautions so that no fingers are placed within the compartment underneath the cover during operation.

5.2.3 Porting (Figure 5.2)

The porting arrangement is preset at the factory based on the application. This arrangement allows the standard discharge port (Port B) to be on any side of the Actuator Module. The "O'clock" port position (e.g. 3 O'clock) refers to Port B.

The porting setup is identified in the model number of the Actuator Module. The model number is located on the Actuator Module and in the Title Page section of the Operators Manual. A description of the Model Number is located in section 5.8 of this chapter.

WARNING

Removing covers exposes pinch points; keep hands and foreign objects clear while operating with covers 12 and 13 removed.




Figure 5.2A Port Locations

Figure 5.2B Port Locations

5.2.3.1 Operation

The Pump Module may be mounted to the Actuator Module with its intake and discharge ports positioned in one of two positions. This affects the internal setup of the Actuator Module and can be changed if required.

5.2.3.2 Porting Adjustment (Figure 5.3)

The following procedure describes changing the orientation of the porting.

Tools Required

1. Philips Head Screwdriver
2. 3/32 Hex Key
3. 5/32 Hex Key

Setup

1. Connect Controller Module to Actuator Module using the cable.
2. Turn power on and reference the system.
3. Change the Controller Module to Meter mode and Load mode to manual.
4. Press START to meter piston fully forward.
5. Remove covers (12) and (13).

WARNING

The linear actuator motor can generate a force capable of causing injury, especially during linear movement. The cover plate guards the operator from hand pinch hazards inside the coupler compartment. While performing the porting adjustment, it is important that the trained operator takes precautions so that the controller does not activate the actuator while fingers are in the compartment.

6. Use 5/32 hex key to remove Pump Module (refer to Chapter 7, leave the piston in place)
7. Loosen, do not remove, #4-40 socket head cap screw (19) (screw may be in a different position)
8. Rotate the piston so the flat lines up with the desired discharge port position (refer to figure 5.2). Do this by rotating the coupling that holds the piston. Use an edge of the coupling housing (1) as a visual reference.
9. Tighten #4-40 socket head cap screw (19).
10. Press the LOAD button on the Controller Module to fully retract the piston.
11. Press the START button to meter the piston fully forward.
12. Recheck piston flat to verify port alignment.
13. Repeat adjustments 7 through 9 if needed.
14. Insure there is approximately 1/32" gap between spool bushing (18) and drive hub (10) when pump is metered forward.
15. Replace Pump Module (refer to Chapter 7).
16. Replace covers (12) and (13).

5.3 INSTALLATION

The Actuator Module contains a mounting bracket and optional gasket for mounting to a panel. Figure 5.4 provides the panel cut-out requirements for ease of installation of the Actuator Module. The position of the Pump Module should be considered when mounting the Actuator Module. Plan to mount so the intake and discharge tubing and the end cap can be easily accessed. Additional consideration should be taken regarding the fluid flow. Always keep the discharge of the Pump Module even with or higher than the intake and never mount the Actuator Module so the pump end cap is above the ports.

5.4 OPTIONS

IVEK Corporation offers a variety of options to best meet the customers' needs. Following is a list and description of available options for the Actuator Module. Refer to the Title Section of this manual for the list of options provided with this system.

5.4.1 Encoder

The encoder option must be present in the channel card (in Controller Module), the interconnecting cable and in the corresponding Actuator Module.

This option adds an encoder to the Actuator Module which allows the channel card to verify all motions of the Actuator Module. Any stall during fluid displacement or valving will immediately be sensed using the encoder, and will generate a fault condition. The encoder works in conjunction with the linear and rotary sensors.


The encoder option is identified in the model number of the Actuator Module. The model number is located on the Actuator Module and in the Title Page section of the Operators Manual. A description of the Model Number is located in section 5.8 of this chapter.

5.5 MAINTENANCE

Minimal maintenance is necessary for this Actuator Module.

CAUTION

Never connect or disconnect the cable from the Actuator Module connector while power is on. Damage to the equipment may result.



5.4 Mounting Panel Cut-Out Requirements

5.6 PROBLEM GUIDE

Table 5.1 contains a list of possible problems, causes and solutions for the Actuator Module.

Table 5.1 Common Operational Problems and Solutions


PROBLEM	PROBABLE CAUSE	POSSIBLE SOLUTION
Controller Module power on and operational, but will not activate Actuator Module.	I/O Cable	Check connection of cable between Controller Module and Actuator Module. Inspect and repair faulty cable.
System is running but not pumping fluid.	Damaged Coupling Loose fitting	If piston not referenced to output, check coupling for damage. Tighten fitting
Rotary or Linear Sensor Fault	Piston seized in cylinder	Remove and soak.
Piston home fault or linear sensor fault	Obstructed optical linear sensor	Inspect and clean optical linear sensor

5.7 SPECIFICATIONS

Motor: 23 Frame 1.8° Stepper
 Lead Screw: 1/4-20 Acme or 1/4-40 60° V Thread
 Lead Accuracy: .0001" / inch noncumulative
 Maximum Stroke: 1/4-20 = 1/2" = 2000 steps or
 1/4-40 = 1/4" = 2000 steps
 1/4-20 with A-20 Option = 1/4" = 1000 Steps


5.8 MODEL NUMBER

The model number provides important information about the specifics of your Actuator Module. Refer to this number when calling IVEK Technical support. The model number for your Actuator Module is located in the Title Page section of this manual.



5.9 ILLUSTRATED PARTS BREAKDOWN

The illustrated parts breakdown (Figure 5.4) contains replacement parts for the Actuator Module.

INDEX NO.	PART NUMBER	DESCRIPTION	UNITS PER ASSY
	032241-#####	Linear Actuator Module	1
<p>032241-1##### 032241-5##### 032241-6#####</p>			
1	032083	Cover Plate	1
2	032128	Thumb Screw Fabrication	2
3	032133	Front Shell Fabrication	1
NS	001576	Adaptor Ring	1
<p>032241-3##### 032241-7##### 032241-8#####</p>			
1	032083	Cover Plate	1
2	032128	Thumb Screw Fabrication	2
3	032132	Front Shell Fabrication	1
<p>NS = Not Shown</p>			
			
<p>Figure 5.5 Actuator Module Replaceable Parts</p>			

CHAPTER REVISIONS

A 12/13/2024 Per DCR/N 22453 & 22455

- 8/6/2020 Original release